

# READ ME



## iP Series Presets for SP260

### Open Preset File:

- 1) Unzip the "iP Series Presets for SP260" file and move the 2 extracted preset (.d26) files to the "SP260 Presets" folder in My Documents.
- 2) Connect the SP260 to your computer, power on and initialize the SP260, then open the SP260 Control Application.
- 3) From the SP260 Control Application, click "File" then select "Open Preset from PC".
- 4) Select the desired preset then click "Open".

### Configure Outputs:

- 1) From the SP260 Control Application, click "Edit" then select "Copy Outputs".
- 2) Select an "Output Source" for the iP Series you plan to connect.
- 3) Select "Output Destination" to copy the settings the desired SP260 output.
- 4) Click "Confirm" then click "Yes" to copy settings.
- 5) Repeat this process until all of your outputs are properly configured.

### Edit Channel Names:

- 1) From the SP260 Control Application click "Edit" then select "Channel Names".
- 2) Click on Channel name field to be edited, then type the new names for this channel.
- 3) When finished with channel naming, click "OK", then click "Yes".

### Save Preset to PC

When you have finished configuring your system using the SP260, save all of your settings as a Preset on your PC for recall and offline editing later.

- 1) From the SP260 Control Application, click "File".
- 2) Select "Save Preset to PC".
- 3) Enter an appropriate file name for your system.
- 4) Click "Save".

### Store Preset to Device:

If you prefer, you can save the entire system's settings as a Preset on the SP260 hardware. This way you can restore the system without connecting a PC if your original settings are inadvertently changed.

- 1) From the SP260 Control Application, click "File".
- 2) Select "Store Preset to Device".
- 3) Enter an appropriate name for your Preset in the field below "Enter new preset name".
- 4) Select the preset number (1-24) from the "Select new preset number" drop-down menu.
- 5) Click "Store", then click "Yes".